



HOW TO DETERMINE MODEL NUMBER

Example: Model VRVR484S

The model number is divided into five (5) sections as noted below:

Model Number:	<u>VRV</u>	<u>R</u>	<u>4</u>	<u>84</u>	<u>S</u>
Item designation	(1)	(2)	(3)	(4)	(5)

- | | | |
|---------------|---|------------|
| Item 1 | All models will begin with | VRV |
| Item 2 | The letter “R” designates a reduction from outer vent to your standpipe. This designation will be used if you elect to use a reducer as described in Item 4 | R |
| Item 3 | The next digit is the size of the internal PVC vent (in inches). The outer steel vent for most standard vents will be 4” larger. In this example, the vent would attach to a 8” flange. | 4 |
| Item 4 | The next two to four digits will be used only if a reducer is required to attach to your standpipe. This example indicates a 8” x 4” reducer. | 84 |
| Item 5 | The last letter indicates stainless bolts. If a “S” is not shown in this location, carbon steel bolts will be provided. | S |

Build your vandal resistant vent model number

<u>VRV</u>				
(1)	(2)	(3)	(4)	(5)